



Models FINR/OINR/OIMNR

DIMENSION REFERENCE	CYLINDER BORE			DIMENSION REFERENCE	CYLINDER BORE		
	1 1/2	2	2 1/2		1 1/2	2	2 1/2
B	1 1/8	1 1/8	1 1/8	MM	5/8	5/8	5/8
C	3/8	3/8	3/8	P	2.29	2.29	2.42
E	1 3/4	2 1/4	2 3/4	R	1.43	1.84	2.19
E1	2	2 1/2	3	TF	2.75	3.38	3.88
E2	2 1/2	3	3 1/2	UF	3 3/8	4 1/8	4 5/8
EE-NPTF	1/4-18	1/4-18	1/4-18	UF/2	1 11/16	2 1/16	2 5/16
F	3/8	3/8	3/8	W	5/8	5/8	5/8
FB	9/32	11/32	11/32	X	1 1/4	1 3/4	2
LB	3 5/8	3 5/8	3 3/4	X/2	5/8	7/8	1
LB1	1 1/2	1 1/2	1 1/2	Y	1.67	1.67	1.67

See Application Information for sensors and magnetic switch options, mounting accessories, special options, and ordering information.